



IBM ThinkPad T42 Battery Replacement

Written By: Kevin Rehm



INTRODUCTION


Changing the battery is easy -- you don't need a any tools.

Step 1 — Battery



- Slide the 2 sliders on the under side of the laptop to the unlock position, as shown.

Step 2



- Grasp the battery and pull it straight out - not at an angle.

To reassemble your device, follow these instructions in reverse order.